

Frequently Asked Questions

Preparation for running application in WOW64 mode

#5400-0378 Version 1.1.0.1

TOSHIBA TELI CORPORATION

Information contained in this document is subject to change without prior notice.

Document in Japanese

このドキュメントは wow64 モードで TeliCamSDK アプリケーションを実行するための準備作業について記述したドキュメントです。日本語ドキュメントは英語ドキュメントの後にあります。

End of document in Japanese

This document describes preparation for running TeliCamSDK application in WOW64 mode.

1. WOW64

64 bit Windows has emulation layer named "WOW64" (Windows 32bit emulation on Windows 64bit) for running 32 bit application program on 64bit OS.

It is necessary to install 32bit dlls that the 32bit application uses on 64bit Windows before running 32bit application in WOW64 mode.

2. Preparation

Do the followings before running 32bit TeliCamSDK application on 64bit Windows.

We recommend users to install the latest TeliCamSDK if running 32bit and 64bit TeliCamSDK application on a Windows OS are required.

In case of TeliCamSDK V1.0.5.1 or earlier, users must take time and effort to edit environment variable "PATH" before running application for switching GenAPI library.

2.1. TeliCamSDK V1.0.6.1 or later

2.1.1. Install 64bit TeliCamSDK.

Run SetupTeliCamSDK_x64.exe to install TeliCamSDK.

GenICam GenAPI reference implementation dlls (both 32bit and 64bit) will be installed and GigE Vision device driver and USB3 Vision device drivers will be registered to OS, by default.

2.1.2. Edit environment variable "PATH"

Please append 32bit "bin" folder of TeliCamSDK to the environment variable "PATH".

32bit "bin" folder is typically "C:\Program Files\Toshiba Teli\TeliCamSDK\TeliCamApi\bin\x86".

TeliCamSDK installer registers 64bit "bin" folder of TeliCamSDK to the environment variable "PATH" in its installation process. Don't care about the order of 32bit bin folder string and 64bit folder string in the environment variable "PATH".

2.1.3. Install 32bit VC++ Redistributable Packages.

Please install the following 32bit VC++ Redistributable Packages.

- ✓ Microsoft Visual C++ 2010 SP1 Redistributable Package
<https://www.microsoft.com/en-us/download/details.aspx?id=8328>

[For TeliCamSDK PkgVer2.1.0.1 or later]

- ✓ Microsoft Visual C++ 2013 Redistributable Package
<https://www.microsoft.com/en-us/download/details.aspx?id=40784>

[For TeliCamSDK PkgVer2.0.1.1 or earlier]

- ✓ Microsoft Visual C++ 2005 SP1 Redistributable MFC Security Update (KB2538242)
<https://www.microsoft.com/en-us/download/details.aspx?id=26347>

TeliCamSDK installer installs 64bit version runtimes in its installing process.

2.2. TeliCamSDK V1.0.5.1 or earlier

In case of TeliCamSDK V1.0.5.1 or earlier, note that users have to switch value of the environment variable "PATH" to select proper GenAPI library dll (32bit dll or 64bit dll) on starting TeliCamSDK application.

2.2.1. Install 64bit TeliCamSDK and drivers.

Run SetupTeliCamSDK_x64.exe or SetupTeliCamSDK_ContainDNet_x64.exe to install SDK.

After installation of TeliCamSDK files, run TeliGevDrvInst64.exe and TeliU3vDrvInst64.exe in TeliCamDriver folder under the folder that TeliCamSDK is installed to install GigE Vision and USB3 Vision drivers.

2.2.2. Install 32bit and 64bit GenAPI library

Refer to "Appendix1. How to install 32bit and 64bit GenAPI library."

2.2.3. Install 32bit VC++ Redistributable Packages.

Please install the following 32bit VC++ Redistributable Packages.

- ✓ Microsoft Visual C++ 2010 SP1 Redistributable Package
<https://www.microsoft.com/en-us/download/details.aspx?id=8328>
- ✓ Microsoft Visual C++ 2005 SP1 Redistributable MFC Security Update (KB2538242)
<https://www.microsoft.com/en-us/download/details.aspx?id=26347>

64bit version runtime has been already installed by installer of TeliCamSDK.

2.2.4. Editing the environment variable "PATH"

Please replace 64bit GenAPI path with 32bit path in the environment variable "PATH" before running 32bit application.

Never forget to replace 32bit GenAPI path with 64bit path in the environment variable "PATH" before running 64bit application.

The followings are the typical GenAPI path.

64bit : C:\Program Files\GenICam_v2_3\bin\Win64_x64

32bit : C:\Program Files\GenICam_v2_3\bin\Win32_i86

Appendix1. How to install 32bit and 64bit GenAPI library.

In the case of TeliCamSDK V1.0.6.1 or later, both 32bit and 64bit binary of GenAPI library are installed by default.

In the case of TeliCamSDK V1.0.5.1 or earlier, 32bit and 64bit GenAPI library installers are installed under TeliCamSDK folder. Users should install GenAPI library manually.

Unfortunately, 32bit GenAPI library will not install 32bit binary if 64bit GenAPI library is already installed. 64bit GenAPI library will not install 64bit binary if 32bit GenAPI library is already installed, either.

Do the following procedure to install both 32bit and 64bit GenAPI library.

- A. Run 64bit GenAPI library installer.
(C:\Program Files\Toshiba Teli\TeliCamSDK\GenICam_v2_3_1\x64\GenICam_VC80_Win64_x64_v2_3_1.exe)
64bit version GenAPI library will be installed in C:\Program Files\GenICam_v2_3\ folder.
- B. Install redistributables in GenICam_v2_3\redist\ folder, if necessary.
Microsoft_VC80_CRT_x64.msi in “redist” folder is an installer for a part of “VC++ 2005 SP1 Redistributable MFC Security Update (KB2538242) (x64)”.
- C. Copy “bin” and “library” folder under GenICam_v2_3 folder to temporary folder.
- D. Run Uninstall.exe in GenICam_v2_3 folder.
64bit GenAPI library will be uninstalled.
- E. Run 32bit GenAPI library installer.
(C:\Program Files\Toshiba Teli\TeliCamSDK\GenICam_v2_3_1\x32\GenICam_VC80_Win32_i86_v2_3_1.exe)
32bit GenAPI library will be installed in C:\Program Files\GenICam_v2_3\ folder.
- F. Copy back 64bit binary files in temporary folder.
Copy temporary folder\bin\Win64_x64\ folder in GenICam_v2_3\bin\ folder and copy temporary folder\library\cpp\lib\Win64_x64\ folder in GenICam_v2_3\library\cpp\lib folder.
- G. Install redistributables in GenICam_v2_3\redist\ folder, if necessary.
Microsoft_VC80_CRT_x86.msi in “redist” folder is an installer for a part of “VC++ 2005 SP1 Redistributable MFC Security Update (KB2538242)”.

1. WOW64 とは

64bit Windows は 32bit アプリケーションを 64bit Windows 上で実行するための WOW64 (Windows 32bit emulation on Windows 64bit) という名称のエミュレーション層を搭載しています。

32bit アプリケーションを WOW64 モードで実行するには、あらかじめアプリケーションが使用する 32bit の dll を 64bit Windows 上にインストールしておく必要があります。

2. 準備作業

TeliCamSDK を使用した 32bit アプリケーションを 64bit Windows 上で実行する前に、本章に記載した準備作業を行なってください。

TeliCamSDK を使用した 32bit と 64bit のアプリケーションを同じ Windows 上で切り替えて使用する場合は、最新の TeliCamSDK をインストールすることをお勧めします。

V1.0.5.1 およびこれ以前のバージョンの TeliCamSDK をご使用になる場合は、アプリケーションを実行する前に、アプリケーションで使用する GenAPI ライブラリを切り替えるために環境変数 PATH を適切な値に編集する手間をかける必要があります。

2.1. V1.0.6.1 以降の TeliCamSDK の場合

2.1.1. 64bit TeliCamSDK のインストール

SetupTeliCamSDK_x64.exe を実行して TeliCamSDK をインストールしてください。デフォルト設定で GenICam GenAPI reference implementation の 32bit と 64bit の dll もインストールされ、GigE Vision と USB3 Vision のデバイスドライバが OS に登録されます。

2.1.2. 環境変数 PATH の編集

TeliCamSDK の 32bit の bin フォルダを環境変数 PATH に追加してください。
32bit の bin フォルダは通常は C:\Program Files\Toshiba Teli\TeliCamSDK\TeliCamApi\bin\x86 です。

TeliCamSDK のインストーラはインストール処理の中で TeliCamSDK の 64bit の bin フォルダを環境変数 PATH に設定しています。環境変数 PATH の中で 32bit の bin フォルダと 64bit の bin フォルダが現れる順番はどちらが先でもかまいません。

2.1.3. 32bit VC++ 再頒布可能パッケージのインストール

以下の 32bit VC++再頒布可能パッケージをインストールしてください。

- ✓ Microsoft Visual C++ 2010 SP1 Redistributable Package
<https://www.microsoft.com/ja-jp/download/details.aspx?id=8328>

[TeliCamSDK PkgVer2.1.0.1 以降の場合]

- ✓ Microsoft Visual C++ 2013 Redistributable Package
<https://www.microsoft.com/en-us/download/details.aspx?id=40784>

[TeliCamSDK PkgVer2.0.1.1 以前の場合]

- ✓ Microsoft Visual C++ 2005 SP1 Redistributable MFC Security Update (KB2538242)
<https://www.microsoft.com/ja-jp/download/details.aspx?id=26347>

64bit VC++再頒布可能パッケージは TeliCamSDK のインストーラがインストールしています。

2.2. V1.0.5.1 以前の TeliCamSDK の場合

V1.0.5.1 以前の TeliCamSDK をご使用の場合は、TeliCamSDK が使用する GenAPI ライブラリ dll (32bit dll と 64bit dll) を適切に選択するために、TeliCamSDK を使用したアプリケーションを実行する前に環境変数 PATH をきりかえる必要がある場合があることを忘れないでください。

2.2.1. 64bit TeliCamSDK とドライバのインストール

SetupTeliCamSDK_x64.exe または SetupTeliCamSDK_ContainDNet_x64.exe を実行して TeliCamSDK をインストールしてください。

TeliCamSDK ファイルのインストール完了後に、TeliCamSDK がインストールされたフォルダの下の TeliCamDriver フォルダにある TeliGevDrvInst64.exe と TeliU3vDrvInst64.exe を実行して GigE Vision と USB3 Vision のデバイスドライバを OS に登録してください。

2.2.2. 32bit と 64bit の GenAPI ライブラリのインストール

「附録. 32/64bit の両方の GenAPI library のインストール方法」を参照してください。

2.2.3. 32bit VC++ 再頒布可能パッケージのインストール

以下の 32bit VC++再頒布可能パッケージをインストールしてください。

- ✓ Microsoft Visual C++ 2010 SP1 Redistributable Package
<https://www.microsoft.com/ja-jp/download/details.aspx?id=8328>
- ✓ Microsoft Visual C++ 2005 SP1 Redistributable MFC Security Update (KB2538242)
<https://www.microsoft.com/ja-jp/download/details.aspx?id=26347>

64bit VC++再頒布可能パッケージは TeliCamSDK のインストーラがインストールしています。

2.2.4. 環境変数 PATH の編集

32bit アプリケーションを実行するときは、環境変数 PATH に記載されている 64bit の GenAPI パスを 32bit のパスに変更する必要があります。

64bit アプリケーションを実行するときは、環境変数 PATH の記載を 64bit の GenAPI パスに戻す必要があります。

GenAPI パスは標準的には以下のパスになります。

64bit : C:\Program Files\GenICam_v2_3\bin\Win64_x64

32bit : C:\Program Files\GenICam_v2_3\bin\Win32_i86

附録. 32/64bit の両方の GenAPI library のインストール方法

V1.0.6.1 以降の TeliCamSDK の場合、インストール直後から 32bit と 64bit の両方の GenAPI ライブラリが使用可能な状態になっています。

V1.0.5.1 以前の TeliCamSDK の場合は 32bit と 64bit の GenAPI ライブラリインストーラが TeliCamSDK のフォルダにコピーされます。GenAPI ライブラリを使用するにはライブラリのインストーラを手動で実行する必要があります。

GenAPI ライブラリのインストーラは、既にライブラリがインストール済みの PC でインストーラを起動してもライブラリのインストールはしてくれません。つまり、64bit GenAPI ライブラリがインストールされている PC で 32bit GenAPI ライブラリのインストーラを起動しても 32bit の dll はコピーされません。32bit ライブラリインストール済み PC で 64bit インストーラを実行しても同様に 64bit の dll はコピーされません。

以下の手順で 1 台の PC に 32bit と 64bit の両 dll をインストールすることができます。

- A. 64bit の GenAPI ライブラリインストーラを実行する。
(C:\Program Files\Toshiba Teli\TeliCamSDK\GenICam_V2_3_1\64\GenICam_VC80_Win64_x64_v2_3_1.exe)
C:\Program Files\GenICam_v2_3\ フォルダに 64bit GenAPI ライブラリが保存されます。
- B. 必要に応じて GenICam_v2_3\redist\フォルダの再頒布可能ランタイムをインストール。
“redist”フォルダにある Microsoft_VC80_CRT_x64.msi は「VC++ 2005 SP1 再頒布可能パッケージ MFC のセキュリティ更新プログラム(x64)」の中の GenAPI で使用するランタイムだけをインストールするためにインストールファイルです。
- C. GenICam_v2_3 フォルダ下の“bin”と“library” のフォルダを暫定フォルダにコピーする。
- D. GenICam_v2_3 フォルダにある Uninstall.exe を実行する
64bit 版の GenAPI ライブラリがアンインストールされます。
- E. 32bit の GenAPI ライブラリインストーラを実行する。
(C:\Program Files\Toshiba Teli\TeliCamSDK\GenICam_V2_3_1\32\GenICam_VC80_Win32_i86_v2_3_1.exe)
C:\Program Files\GenICam_v2_3\ フォルダに 32bit GenAPI ライブラリが保存されます。
- F. 暫定フォルダにコピーした 64bit 版バイナリファイルを GenICam_v2_3\ フォルダに戻す。
暫定フォルダの bin\Win64_x64\フォルダを GenICam_v2_3\bin\フォルダに、暫定フォルダの library\cpp\lib\Win64_x64\ フォルダを GenICam_v2_3\library\cpp\lib フォルダにコピーしてください。
- G. 必要に応じて GenICam_v2_3\redist\フォルダの再頒布可能ランタイムをインストール。
“redist”フォルダにある Microsoft_VC80_CRT_x86.msi は「VC++ 2005 SP1 再頒布可能パッケージ MFC のセキュリティ更新プログラム」の中の GenAPI で使用するランタイムだけをインストールするためにインストールファイルです。

End of document in Japanese

3. Others

3.1. Revision History

Date	Version	Description
2016/06/21	1.0.0	Created the initial version
2017/04/04	1.1.0	Appended description for TeliCamSDK PkgVer2.1.0.1 or later.

3.2. Disclaimer

The disclaimer of this document including example code is described in "License Agreement TeliCamSDK Eng.pdf" in TeliCamSDK installation folder.

Make sure to read this Agreement carefully before using it.

Refer to TeliCamSDK installation folder/Documents/License folder